VDS Diagnostics

Types of Diagnostics


Auto-diagnosis tools

- Machine builder
- Forcing Orders
- Machine Speed
- Baselines (Averages)

Auto diagnostic features come from the machine class. Machine class holds information such as machine elements (mechanical parts) forcing orders, speed/RPM and data collection points. Information on machine class contruction can be found here: VDS Machine Builder

Alarms


Alarms are a tool directly tied to a measurement entry, the rms and crest factor values are manually set for the entry




Fixed Thresholds & Baselines


Creation

Fixed thresholds and baselines are both created by selecting a point or machine class in the asset explorer and then navifating to the machine class page in the data explorer. Then right click on the pickup point you would like to create the baseline for and select average for a baseline or fixed threshold for a fixed threshold.



Fixed thresholds






}}


Diagnosis

Diagnostic information will be processed for the test group when route data is collected and uploaded to VDS if the option for auto-diagnostic processing is checked. Otherwise, the data can be processed by right clicking the data under the data explorer in selected point and clicking create diagnosis.

Report

Diagnostic information can be viewed in the review panel by selecting the View Diagnosis feature or by exporting the information from the tool page and selecting Diagnosis.
Information includes fault diagnosis, severity, confidence interval, and recommended action





From:
https://help.go-ci.com/ - **Crystal Instruments Help**

Permanent link:
https://help.go-ci.com/vds:diagnostics?rev=1782421105

Last update: **2026/06/25 20:58**