



# Post Analyzer Data

## Importing Data


Data is imported into Post Analyzer at the start of a new project by either selecting data from the Add single source file




Or from the option Data File Browser which connects you to all EDM files within your PC



Files loaded into project will appear in the Source files tab while all data processed within project will appear in the live signals tab and saved data will appear in the run folders tab




Data Source files can also be found through the Setup → Data Sources which will open a Data Source window in the main display




## Exporting Data

Data can be exported in number of ways. The simplest of ways is to right click on the desired plot in the window and select Report/Export Window → Export Displayed Portion of Signals → Export




Saved files will appear under the Run folders tab. Saved files can be exported by right click → export.




Several saved files can be exported simultaneously through the batch export feature which is labeled

export and is found in the top right of the run folders window.



Live signals can be exported through right click → export as well



Data can be collected through the report feature as well.

From: <https://help.go-ci.com/> - **Crystal Instruments Help**

Permanent link: <https://help.go-ci.com/pa:data>

Last update: **2026/04/14 20:21**