

Real Time RMS

The **Real Time RMS** page can be accessed by connecting to a Ruby via Bluetooth, where it shows the numeric display.



For more details on how to move and zoom around in the signal display, see [Moving and Zooming around in the Signal Display Traces](#) or [Navigating Signal Display Controls](#).

From:

<https://help.go-ci.com/> - **Crystal Instruments Help**

Permanent link:

https://help.go-ci.com/ruby:ios:real_time_rms_ios?rev=1752515875

Last update: **2025/07/14 17:57**