


## Loading and Unloading Data from CoCo



- 1. First Connect your CoCo device by ethernet to your PC.
- 2. In VDS, click **Data Collector** > in the **Devices** menu, click **Load** > Click **CoCo device** > **Select the Device you are using** > Click **Connect** then **Next** > Click **Load Factories and Routes** > Click **Next**
- 3. Your VDS will have Factories and Routes to choose to upload to your CoCo device.  
**Select options to upload** > Click **Upload** > Click **Finish**

To Unload, follow the same steps from above after clicking **Unload** from the **Devices** menu.

From:  
<https://help.go-ci.com/> - **Crystal Instruments Help**

Permanent link:  
<https://help.go-ci.com/vds:transfer?rev=1734726822>

Last update: **2024/12/20 20:33**