

Accessing Saved Information

Run Folders



SIG Files contains information from **Save** functionality, includes block and frequency domain data

REC Files contains information from Recording functionality, includes time domain data. Record destination can be internal to the spider hardware or external to the PC

Time History Files contains profile RMS history, ramp up speed and run at level information is displayed here.

Change Saved Folder

Single Test

Setup → Test Configuration → File Directory



All Tests

Tools → Global Settings → Working Folder



Downloading Data from Spider



Tools → Download From Spider Internal Storage

1. Download/Download Page configures files by Rec and SIG data folders
2. Run Log configures data by Test

Tools → Download from Spider NAS/NASi

1. Download data recorded to NAS/NASi

Export Data



Export Run Folder: Right-Click → Export to Single File

Export SIG/REC File: Right-Click → Export

Export Specific Channel Data: Right-Click → Export

From:

<https://help.go-ci.com/> - **Crystal Instruments Help**

Permanent link:

<https://help.go-ci.com/accessing-saved-information>

Last update: **2026/02/20 16:43**