


Setup a Post Analyzer test

Before starting, a file with recorded data in the form of .atfx, .csv, or .txt should be accessible to add into EDM.

In the beginning, you will see the New Project Wizard window.



1. Choose your project type, and click **Next**.
2. Insert your project name, and click **Add single source file** to add your source file
3. Click the checkboxes under the file just added to be included in the analyzation, and click Next
4. Choose the signal types to be computed

From:

<https://help.go-ci.com/> - **Crystal Instruments Help**

Permanent link:

<https://help.go-ci.com/pa:setup?rev=1750798600>

Last update: **2025/06/24 20:56**