To record data in the ruby mobile app, connect to a Ruby via **USB**. This will make the **Spectral Analysis** available to use via the main page.



To edit any recording settings, tap the **Parameters** button to open a menu and **slide to the left** to reveal the **Record Setup** button. Tap on the **Record Setup** button to edit what signals to record and how many points or how long to record.

Parameters × Analysis Pa Location ID
Image: Traces Image: Control Image: Control Image: Control Image: Control < Record Setup
Record Signals ch1,ch2,ch3 >
Point Number Duration
Point Number 512

Then tap on the **Control** button to open a menu that contains the **Record** button. Tap the **Record** button to record a signal that will be stored in the Ruby device.



The file will have to be manually downloaded in **Device** > **Files** to view the data.

For more details on viewing or downloading the data, see Viewing Data in the Ruby Mobile App.

